

## MPI Tutorial-6 8086 Arithmetic Operations ALPs

# By Dr. Sanjay Vidhyadharan



#### **Problem-1: Square root of a Number**

Write an assembly language program in 8086 microprocessor to find square root of a number.

AX	BX	AX- BX	СХ	CX=CX+1 and BX=BX+2 if AX ≠BX
25	1	24	1	Assume CX=0 initially
24	3	21	2	
21	5	16	3	
16	7	9	4	
9	9	0		

#### **Problem-1: Square root of a Number**

Write an assembly language program in 8086 microprocessor to find square root of a number.

AX	BX	AX- BX	СХ	CX=CX+1 and BX=BX+2 if AX #BX
49	1	48	2	Assume CX=1 initially
48	3	45	3	
45	5	40	4	
40	7	33	5	
33	9	24	6	
24	11	13	7	
13	13	0		

Write an assembly language program in 8086 microprocessor to find square root of a number.

#### Solution:

#### Algorithm:

- 1. Move the input data in register AX
- 2. Move the data 0000 in CX and FFFF in BX
- 3. Add 0002 to the contents of BX
- 4. Increment the content of CX by 1
- 5. Subtract the contents of AX and BX
- 6. If Zero Flag(ZF) is not set go to step 3 else go to step 7
- 7. Store the data from CX to offset 600
- 8. Stop
  - 2/25/2021 \*N.B.: Will only work for perfect squares.

Write an assembly language program in 8086 microprocessor to find square root of a number.

#### Solution:

MOV AX, [0500H] //Place where the number is stored MOV CX, 0000 MOV BX, FFFF L1: ADD BX, 02 INC CX SUB AX, BX JNZ L1 MOV [0600H], CX //Place where the result is stored HLT

✤N.B.: Will only work for perfect squares.

Write a program to find the min value in a given array in assembly 8086 microprocessor



231

Write a program to find the min value in a given array in assembly 8086 microprocessor

Solution:

- 1. Assign value 500 in SI and 600 in DI
- 2. Move the contents of [SI] in CL and increment SI by 1
- 3. Assign the value 00 H to CH
- 4. Move the content of [SI] in AL
- 5. Decrease the value of CX by 1
- 6. Increase the value of SI by 1
- 7. Move the contents of [SI] in BL
- 8. Compare the value of BL with AL
- 9. Jump to step 11 if carry flag is set
- 10. Move the contents of BL in AL
- 11. Jump to step 6 until the value of CX becomes 0, and decrease CX by 1
- 12. Move the contents of AL in [DI]
- 13. Halt the program

#### 2/25/2021

Write a program to find the min value in a given array in assembly 8086 microprocessor

ADDRESS	MNEMONICS	COMMENTS
0400	MOV SI, 500	SI ← 500
0403	MOV DI, 600	DI ← 600
0406	MOV CL, [SI]	CL ← [SI]
0408	MOV CH, 00	CH ← 00
040A	INC SI	SI ← SI+1
040B	MOV AL, [SI]	AL ← [SI]
040D	DEC CX	$CX \leftarrow CX-1$
040E	INC SI	SI ← SI+1
040F	MOV BL, [SI]	$BL \leftarrow [SI]$
0411	CMP AL, BL	AL-BL
0413	JC 0417	Jump if carry is 1
0415	MOV AL, BL	$AL \leftarrow BL$
0417	LOOP 040E	Jump if CX not equal to 0
0419	MOV [DI], AL	[DI] ← AL
1041B	HLT	End of the program
	0400 0403 0406 0408 040A 040B 040D 040D 040E 040F 0411 0413 0413 0413 0415	0400         MOV SI, 500           0403         MOV DI, 600           0406         MOV CL, [SI]           0408         MOV CH, 00           040A         INC SI           040B         MOV AL, [SI]           040D         DEC CX           040F         MOV BL, [SI]           0411         CMP AL, BL           0413         JC 0417           0415         MOV AL, BL           0417         LOOP 040E           0419         MOV [DI], AL

#### **REPE/REPNE/REPZ/REPNZ**

**REPE** and **REPZ** are mnemonics for the same prefix; they stand for Repeat if Equal and Repeat if Zero respectively. REPE/REPZ causes the succeeding string instruction to be repeated as long as the compared bytes or words are equal (ZF = 1) and CX is not yet counted down to zero.

The **REPNE** and the **REPNZ** instructions stand for Repeat if Not Equal and Repeat if Not Zero respectively and cause the string instruction to be repeated until the compared bytes or words are equal (ZF = 1) **or** until CX = 0 (end of string.)


Instruction Code	Condition for Exit
REP	CX = 0
REPE/REPZ	CX = 0 or $ZF = 0$
REPNE/REPNZ	CX = 0  or  ZF = 1



The SCAS instruction is used for searching a particular character or set of characters in a string. The data item to be searched should be in AL (for SCASB), AX (for SCASW) or EAX (for SCASD) registers. The string to be searched should be in memory and pointed by the ES:DI (or EDI) register.

	Instruction	Description
	SCASB	Affect the flags based on the result of AL-ES:[DI] ; IF (DF=0) DI=DI+1 ELSE DI=DI-1
	SCASW	Affect the flags based on the result of AX-ES:[DI+1:DI] ; IF (DF=0) DI=DI+2 ELSE DI=DI-2
531	SCASD	Affect the flags based on the result of EAX-ES:[DI+3:DI] ; IF (DF=0) DI=DI+4 ELSE DI=DI-4

- Write an assembly language program in 8086 microprocessor to search a number in a string of 5 bytes, store the offset where the element is found in DX and the number of iterations used to find the number in BX.
- For e.g. if the numbers in the memory location starting from location 0600H is given as follows and we have to find the number 25:



```
MOV AX, 2000 //starting location of ES
MOV ES, AX
MOV DI, 600 //starting location of first string
MOV AL, 25 //The number to search
                   //No. of items
MOV CX, 0005
MOV BX, CX
CLD
REPNE SCAS B
                   //Repeat till ZF = 0. Scan value from [DI]
                   and compare with AL, Increment DI
DEC DI
MOV DX, DI
SUB BX, CX
DEC BX
INT 03H
```

Write an ALP to find 2's complement of a string of 100 bytes.



Write an ALP to find 2's complement of a string of 100 bytes.

- 2000 CLD
- 2001 MOV SI, 4000 H
- 2004 MOV DI, 5000 H
- 2007 MOV CX, 0064 H
- 200A LODSB
- 200B NEGAL
- 200D STOSB
- 200E LOOPNZ 200A H 2010 HLT

- : Clear direction flag
- : Source address put in SI
- : Destination address put in DI
- : Put the number of bytes to be 2's Complemented in CX
- : Data byte to AL and INC SI
- : 2's Complement of AL
- : Current AL value into DI and INC DI
- : Loop till CX = 0.
- : Stop.

# Thank You

c31)

han an