



# Microprocessor Programming and Interfacing

## Lecture-2 : Introduction to Microprocessors


Dr. Sanjay Vidhyadharan

Assistant Professor

EEE Department

BITS Pilani Hyderabad Campus

# Introduction to Microprocessors




# Introduction to Microprocessors


## Microprocessor vs. Microcontroller



### Microprocessor



### Microcontroller



# Introduction to Microprocessors

You may pause this video now and watch the video from the link provided .


<https://www.youtube.com/watch?v=9Rrt0n1oY8E>

# Introduction to Microprocessors

## Microprocessor



## Microcontroller



# Instructions in Microprocessor

## WHAT IS INSTRUCTIONS?

Tells the  $\mu$ p what action to perform

Sanjayvidhyadharan.in

# Instructions in Microprocessor

## HOW DOES A MICROPROCESSOR HANDLE AN INSTRUCTION?


### Fetch Cycle

The fetch cycle takes the instruction required from memory, stores it in the instruction register


### Execute Cycle

The actual actions which occur during the execute cycle of an instruction

# Introduction to Microprocessors




# Introduction to Microprocessors



**Block Diagram of a Microprocessor**

# Microprocessor Bus

## PROCESSOR BUS



## ADDRESS BUS:

No of Address lines

- 20 lines – $A_{19}$ – $A_0$
- 1 M Byte of memory can be addressed

## DATA BUS:

No of Data lines

- 16 lines – $D_{15}$ – $D_0$

## CONTROL LINES:

-Active low signals

- MEMR
- MEMW
- IOR
- IOW

# Memory of Microprocessors

## PROCESSOR MEMORY

- **ROM**

Non-Volatile

Read Only

- **RAM**

Volatile

Random Access Memory

# Processors

- **CISC (Complex Instruction Set Computer)**

Operands for Arithmetic/Logic operation can be in Register/ Memory

- **RISC (Reduced Instruction Set Computer)**

Operands for Arithmetic/Logic operation only in Registers

Register –Register Architecture

# RISC vs CISC

**Goal:** Multiply data in mem A with B  
and put it back in A

**CISC:**

MUL A,B


**RISC:**

LDA R<sub>0</sub>,A

LDA R<sub>1</sub>,B

MUL R<sub>0</sub>,R<sub>1</sub>

STR A,R<sub>0</sub>



# RISC vs CISC



[https://www.youtube.com/watch?v=\\_EKgwOAAWZA&feature=emb\\_title](https://www.youtube.com/watch?v=_EKgwOAAWZA&feature=emb_title)


# Introduction to Microprocessors

You may pause this video now and watch the video from the link provided .

[https://www.youtube.com/watch?v=\\_EKgwOAAWZA](https://www.youtube.com/watch?v=_EKgwOAAWZA)

# Basic Parallel Techniques


- Pipelining
- Replication



## INSTRUCTION PIPELINES


Instruction:

- Fetch
- Decode
- Execute




# FLYNN'S TAXNOMY

## 1. SISD: Single Instruction, Single-Data Systems





# FLYNN'S TAXNOMY

## 2. SIMD : Single-Instruction, Multiple-Data Systems





# FLYNN'S TAXNOMY

## 3. MISD : Multiple-Instruction, Single-Data Systems





# FLYNN'S TAXNOMY

## 4. MIMD: Multiple-Instruction, Multiple-Data Systems




# Multi-Core Processors

Dual CPU Core Chip



# Multi-Core Processors



$$\text{Energy stored in } C_{Load} (C_L) = \int_0^{V_{DD}} V_C \cdot C_L dV_C = \frac{1}{2} \cdot V_{DD}^2 \cdot C_L$$

$$\text{Energy consumed from power supply} = V_{DD} \int_0^T i(t) dt = V_{DD} \cdot Q_{CL} = V_{DD}^2 \cdot C_L$$

$$\text{Energy dissipated in pMOSFET during charging} = \frac{1}{2} \cdot V_{DD}^2 \cdot C_L$$


$$\text{Energy dissipated in nMOSFET during discharging} = \frac{1}{2} \cdot V_{DD}^2 \cdot C_L$$

$$\text{Power Consumption} = \text{Frquency} \cdot V_{DD}^2 \cdot C_L$$


# Multi-Core Processors

PARALLEL PROCESSING AT LOWER SUPPLY VOLTAGE

$$P_{\text{Switching}} = \eta f_{\text{Clk}} C_L V_{\text{DD}}^2$$



# Multi-Core Processors



Quad-core  
microprocessor

# Introduction to Microprocessors

## CPU on a Single VLSI Chip

### WHAT HAPPENS WHEN YOU TURN ON YOUR COMPUTER ?

BIOS –Basic Input Output System

- Resident in ROM

Orchestrates loading the computer's operating system from the hard disk drive into RAM. **Why RAM?**

OS Loads Program from Disk (Secondary Storage) to RAM (Primary Storage)

(Program -Set of Instructions –Executed by  $\mu\text{p}$ )

# EVOLUTION OF MICROPROCESSOR

Name	Date	Transistors	Clock speed	Data width
8080	1974	6K	2MHz	8
8086	1978	29K	5MHz	16
80286	1982	134K	12 MHz	16
80386	1985	275K	16-33 MHz	32
80486	1989	1.2 M	20 -100 MHz	32
Pentium	1993	3.1M	60-200 MHz	32 /64
Pentium II	1997	7.5 M	233-450 MHz	32/ 64
Pentium III	1999	9.5M	450 -933 MHz	32 /64
Pentium 4	2000	42 M	1.5 GHz	32/ 64

an.in

**Thankyou**